



Do not tighten fixings until the assembly is complete. The lock washers are next to the nuts. Please separate the bolts and nuts by size before starting the assembly.

1. Carefully turn the bottom bowl (D) upside down and attach the three legs (F) by inserting the six M6 X 20 bolts (J), washers (L), lock washers (M) and nuts (K). Leave the fixings loose.
2. Stand the bottom bowl on the three legs and attach the connection plates (H) to the bottom bowl (D) by inserting three M6 X 20 bolts (J), washers (L), lock washers (M) and nuts (K).
3. Attach top bowl (C) to bottom bowl (D) using the connection plates (H) and inserting three M6 X 20 bolts (J), washers (L), lock washers (M) and nuts (K).
4. Install the funnel (B) to the top bowl (C) by insert three M6 X 30 bolts (I), washers (L), lock washers (M) and nuts (K).
5. Attach mesh door hook (G) on the left of top bowl (C) with pre assembled bolts and nuts, then assemble spark guard (E) to the right of top bowl (C) with pre assembled bolts, washers, lock washers and nuts.
6. Put rain lid (A) on funnel (B). Now check and tighten all fixings, assembly is complete. **DO NOT OVER TIGHTEN THE FIXINGS WHICH MAY CRACK THE CAST IRON.**