

Thank you for purchasing an Outdoor Revolution product.
This product will give years of satisfactory service if basic
instructions are followed. Our products are designed for
durability, longevity and ease of erection.



WWW.OUTDOOR-REVOLUTION.COM

UNIT 1 BRICK PARK
BRETFIELD COURT
BRETTON STREET INDUSTRIAL ESTATE
DEWSBURY
WEST YORKSHIRE
WF12 9BY

In the interest of continuous development and improvements by Outdoor Revolution; some products or
specifications may vary slightly from the photographs and information provided in this instruction manual.
Dimensions and weights are approximate and intended as guidelines only.



**OUTDOOR
REVOLUTION**
WWW.OUTDOOR-REVOLUTION.COM

AIREDALE 7.0SE

INSTRUCTIONS & CARE MANUAL



**OUTDOOR
REVOLUTION**
WWW.OUTDOOR-REVOLUTION.COM

IMPORTANT: PLEASE CHECK YOUR EQUIPMENT

1 X TENT CANVAS

1 X 7 BERTH INNER TENT

1 X DUAL ACTION HAND PUMP

3 X STEEL POLES

1 X BAG OF GROUND PEGS

1 X REPAIR KIT

GUYLINES

STORM STRAPS WHERE APPLICABLE



We highly recommend that you insure your family tent against storm damage, or accidental damage, as the warranty does not cover such eventualities. The manufacturer **IS NOT** liable for any damage caused to the family tent, or its contents, due to misuse, incorrect pitching or extreme weather; full warranty details can be found on the rear of this booklet.

THE GUARANTEE (CONTINUED)...

registered in accordance with the manufacturer's registration process.

OR reserves the right to appoint its own representative to inspect the awning/tent, tube or associated components, prior to any repair or replacement of part(s) covered.

Replacement INTELLIGENT FRAMES under the lifetime guarantee will be dispatched to any UK mainland address free of Charge. Shipping charges covering the cost to dispatch the INTELLIGENT FRAMES to destinations outside of the UK mainland will be applied and payable before being despatched. (**Please note this service may take over 3 days).

Covered components of the Lifetime Warranty

The Lifetime Warranty is valid only for the following components of the awning or tent::

The air tube containing the IF (Intelligent Frame) only

Maintenance repairs and general wear and tear are not covered by the Lifetime Guarantee.

1.3. Customer duties to retain warranty

Online Registration of product is required to validate the Lifetime Warranty; the warranty automatically ceases on re-sale of the product.

The recommended pressure is of 6PSI; as soon as air is heard releasing from the IF valve, inflation must cease.

The warranty does not cover deliberate defacement, human error, misuse or accidental damage; the Lifetime Warranty is a guarantee against manufacturing flaws, solely of the tube.

1.4. Data protection

The activation and validation of the Lifetime Warranty requires OR to maintain personal data of the owner. Blue Diamond Products Limited and Outdoor Revolution will not pass your data onto any third parties and we will not use your data for any marketing purposes without your consent.

LIFETIME GUARANTEE

This warranty provided by the manufacturer does not adversely affect the statutory rights of the purchaser against the seller and gives remedies in addition to those against the seller under the contract of sale. Claims by the purchaser, in particular for a defect on an Intelligent Frame (IF), against the selling Outdoor Revolution distributor remain unaffected by the warranty.

Outdoor Revolution (hereinafter called "OR"), a subsidiary of Blue Diamond Products Ltd group, and its successors in title, warrants for awnings, or tents, using IF technology, of their manufacture:

12 months, without limitation, a warranty against all manufacturing defects of the entire product.

1. LIFETIME WARRANTY OF THE INTELLIGENT FRAME FOR THE FIRST REGISTERED OWNER

1.1. Duration of Warranty

OR undertakes that each new awning/tent supplied thereon by OR as original equipment will be free from defect in material or workmanship according to the state of the art under normal use and service for the Lifetime of the awning/tent. The warranty is valid for the first registered owner of the awning/tent, who bought the product at an OR Authorised Retailer.

The warranty starts on the date of first registration, THIS MUST BE WITHIN 30 DAYS OF PURCHASE.

1.2. Coverage of the Lifetime Warranty

The warranty applies to free of charge repair, or replacement of the IF tube by OR i.e. OR's obligations under this warranty being limited to repairing or replacing at its option any parts or Tube by either OR, or an OR Authorised Repairer. The repair or replacement of defective parts under this undertaking will be made by the Authorised Repairer to whom the awning is returned, free of charge to the customer.

For the parts fitted during a repair, until expiry of the warranty limitation according to Paragraph 1, the same warranty is given as for the awning, tent, frame or associated parts i.e. the warranty is not extended by the repair or replacement of parts even for the parts rectified or replaced. Replaced parts become the property of OR.

Lifetime Warranty cover is dependent upon confirmation that the awning/tent has been

IMPORTANT INFORMATION

- ◆ Please do not leave for your holiday without fully erecting and checking that you have all the listed contents for your family tent. If you are missing anything, then please contact your retailer immediately before use.
- ◆ Please note that man-made fabrics are prone to condensation, when the warm air and moisture within the family tent, comes into contact with the colder air on the outer material. This is a perfectly natural occurrence and should not be confused with leaking. Please ensure that all ventilation points remain open, whenever possible, to help combat condensation.
- ◆ We suggest that you pitch your family tent for some period before use, enabling it to undergo the 'weathering' process. Weathering sometimes requires a few uses of the family tent, before it becomes fully effective. Seam sealant can be used to resolve any persistent weeps; this is a natural process. 'Weathering' is the process of allowing your family tent to become soaked, then completely dry, approximately two to three times, in order to reinforce the waterproofing of the seams/stitching on the fabric.
- ◆ Please ensure that you site the family tent on clear/level ground before erecting, with no sharp objects beneath and any zips fully closed. We suggest placing a groundsheet underneath the family tent to keep it dry/clean.
- ◆ We suggest conducting a trial run of your family tent to familiarise yourself with the assembly and usability of the model. Should you have any issues in relation to pitching your family tent; please contact your dealer for assistance before your holiday.
- ◆ Please note that this model is designed for short term usage and not long term pitch.
- ◆ Always properly dry/air the family tent after use, before packing away, to prevent mildew or mould from developing.
- ◆ Any dirt or stains can be removed by brushing, or gently washing, using warm water. DO NOT use detergents, as this will destroy the waterproofing of the materials.
- ◆ DO NOT cook or smoke inside this family tent, as despite the outer fabric being flame retardant, it will still melt.
- ◆ In the event of damage; please contact your retailer. If, for whatever reason, you are unable to contact them, then please email cs@blue-diamond-products.co.uk and our dedicated customer service team will be pleased to assist you.
- ◆ Please avoid using this family tent in temperatures below freezing, as this can result in cracking of the Oxygen Air Frame.
- ◆ Always store your family tent flat, never on the side of the bag, in a cool/dry area, to avoid any detrimental impact on the Oxygen Air Frame.

OPTIONAL ACCESSORIES

Stone Protection Footprint – A heavy duty groundsheet underlay, which has a 10,000mm hydrostatic head and is designed to safeguard against sharp rocks or harder ground.

Lounge Liner—A water repellent internal roof liner, which can be toggled into the roof to help maintain a comfortable internal temperature and attribute further water resistance.

Carpet—A thermal backed rug-style camping carpet, which covers your entire internal living space, allowing for more comfortable footing.

Airedale Windbreak—A premium four panelled five metre windbreak to effectively deflect any wind around your family tent, whilst directly coordinating with the canvas material used in our 'Airedale' collection.

Lumi-Link Tube Light Kit—A set of three 50cm LED strip lights, which can be attached to this family tent to illuminate the entire internal space, featuring six dimmable brightness settings and three power options.

12V DC Electric Pump—A compact high quality, reliable high pressure air pump designed to inflate modern air tents.

Visit www.outdoor-revolution.com for more information.

LIFETIME GUARANTEE

The Oxygen Air Frame Tubes incorporate an exclusive **LIFETIME GUARANTEE** against any manufacturing faults.

You must register for the **LIFETIME GUARANTEE** on the Outdoor Revolution website within **30 days** of the purchase to **validate** your warranty.

Terms and Conditions apply. Read the full T&C on our website!

- Damage caused by incorrect maintenance of the product.
- Flaws in the fabric caused by excessive use.
- Imperfections or pulls in mesh doors due to wear and tear.
- Water ingress through fabric as a result of accelerated UV degradation due to long term pitch.
- Water ingress through seams caused by excessive abrasion of seams or taped seam.
- Broken zips caused by over tensioning, forcing or snagging.
- Over tensioned/stretched seams coming apart.
- Buckles subjected to undue force or abrasion.
- Lost or popped out eyelets.
- Broken holdalls.
- Pole breakage or tube punctures (where applicable).
- Collateral damage from a pole breakage.
- Condensation, (a natural occurrence, exacerbated by insufficient ventilation opening).
- Consequential damage/loss to property/belongings (either inside or outside of the product) or shortening of holidays.

Outdoor Revolution work very closely with our retail partners to manage all warranty repairs or issues:

Please contact your retailer immediately (even if purchased online) if you feel your Outdoor Revolution product has a genuine warranty issue. The retailer, in turn will raise the issue with ourselves and we will action; with the retailer, according to the nature of the claim.

Returning Products

Please ensure the product is clean and dry and as close to its original condition as possible before sending back for checking. Wet or dirty products will not be accepted back for checking/warranty claims.

It is important to note that the Sales Contract between yourself and the retailer you purchased the Outdoor Revolution product from, remains valid throughout any warranty claim and your statutory rights are not affected.

OUTDOOR REVOLUTION GUARANTEE

Outdoor Revolution products are designed and produced to the very highest of manufacturing standards, using the best quality fabrics or components available for each specific model. Rigorous quality control of finished products is in place.

All manufactured products are:

- Quality controlled to be free from minor defects.
- Fit for the purpose that they are intended for.
- Manufactured to a satisfactory quality.

It is important that correct care is taken when opening, erecting, using, and just as importantly, packing away the product. Following these rules will keep your product in reliable working condition for many years. Failure to adhere to these simple guideline may cause unnecessary damage to the product (see formal instructions for handling or erection tips). A repair kit is included with each of our products to help resolve any minor issues.

THE WARRANTY

The Outdoor Revolution Warranty lasts for twelve months from the original date of purchase; please keep all receipts or copies of any relevant transaction to substantiate the purchase date. This warranty only covers the workmanship, fabric and components. Any faults found within six months of purchase will be investigated by Outdoor Revolution. Faults found outside of the initial six months of purchase will need to be proven by you, the purchaser, in line with current consumer legislation, after the short term right to reject has concluded. **Please note that this warranty requires registration on our website.**

Retailer will not refund a purchase if no fault is found.

The manufacturers warranty does not cover the following:-

- General wear and tear over extended periods of use or, seasonal pitching of the product.
- Accelerated UV damage caused by excessive, long term sun exposure.
- Accidental damage caused by but not exclusive to, human, animal or weather.

PLEASE READ THE INSTRUCTIONS CAREFULLY

TIP: Refer to the photographs below for assistance when erecting your **Tent**.

1. Spread the canvas out flat on the ground, wherever you wish to pitch it. And make sure all doors and fly screens are zipped closed.



2. Secure the four corners of the family tent down, using the adjustable pegging points to hold the tent in position whilst you inflate it; these may require readjustment afterwards.

3. Locate the Middle Beam's 'Dynamic Speed Valve' and ensure that the valve is **closed** before attaching the pump, the valve is **closed** when the button is in the external position.



4. Attach the pump to the 'Dynamic Speed Valve' and carefully inflate, ensuring that none of the fabric is caught anywhere.

5. Inflate the Oxygen Air Frame until the intelligent frame valve (IF valve) expels any excess air, at this point remove the pump and go inside the tent and push the beam upwards to help it take its shape.




6. Replace the cap on the valve and cover it with the Velcro sleeve to maintain a neater external aesthetic. Repeat steps #3 to #6 with the remaining tubes.

7. thread the poles through the side annex and Peg down the front of the family tent, using any adjustable pegging straps to tension the Annex, as much as you desire; please ensure that you do not over tension the fabric whilst doing this.



8. Secure all available pegging points, guylines, or storm straps, starting from one corner, before working your way around.

9. Place the separate groundsheet in the designated porch space, before securing any eyelets as tautly as possible, using the included steel ground pegs.



TRUBLE SHOOTING

<u>PROBLEM</u>	<u>REASON</u>	<u>SOLUTION</u>
The Oxygen Air Frame is deflating after removing the pump.	The 'Dynamic Speed Valve' button hasn't been pressed back out.	Push the quick release button back out to close the valve.
The family tent is leaking water.	This family tent requires 'weathering' before it fully seals itself, therefore you may experience some weeping. This could also be condensation; an inevitable occurrence.	Allow the family tent to get completely soaked, then fully dried, two to three times. Open any ventilation points to optimise air circulation and reduce condensation.
Bowing and twisting of the tubes.	The tubes may twist when inside the sleeves, especially when packing away, so next time the tube bows...	Unzip the sleeve, whilst the tube is deflated, then reposition the tube.

IN THE EVENT OF A PUNCTURE

If you locate a small puncture in your Oxygen Air Frame Tube, you can easily repair it, using the standard puncture repair kit, which should be packed with your model.

- ◆ To remove the air frame tube; deflate the tube, unzip the two protective sleeve covers and pull it out. Please do not unzip the sleeves whilst the tube is inflated.
- ◆ Scrutinise the tube for any punctures and repair the puncture on the Oxygen Air Frame bladder using the inclusive adhesive repair patch.
- ◆ Place the Oxygen Air Frame Tube back into the sleeve, in the correct position, with the valves in their respective sockets, ensuring that the bladder is not twisted.
- ◆ Zip each of the two external sleeves back up.
- ◆ Begin to inflate the Oxygen Air Frame Tube again, ensuring that the puncture repair has been successful.
- ◆ If this process does not work, then you may need to purchase a new bladder.

****Spare Oxygen Air Frame bladders can be purchased to replace damaged ones. Visit the spares section at: www.outdoor-revolution.com**

****Awnings & Tents will not be replaced due to damaged bladders****

PACKING AWAY YOUR PRODUCT

- ◆ Zip up any windows and leave all doors 1/4 open to allow air to escape before deflating.
- ◆ Unpeg all guylines, storm straps and most of the pegs around the product, take the poles out of the side annex, leaving just the four corners pegged out.
- ◆ Open each of the Dynamic Speed Valves in turn and push in the quick release button; leave this button pressed in.
- ◆ Unpeg each of the four corners.



Allow the Product to collapse on itself. Compress as much air out of the tubes and canvas as possible.

Fold the canopy of the Canvas on top of the the rest of the Tent.



Fold the product on itself to create a streamlined 'sausage' shape. Measure the width of the folded tent against the bag to ensure that it will fit inside. Begin rolling the tent towards the valves, pushing out any air as you roll.

Place the rolled product into the holdall, pull the sides up around it, then zip up the holdall.



10. Please lay the inner tent in the designated space, with the door facing the front. Match the coloured elastic to the corresponding coloured loops and begin to work your way around, clipping the inner tent in.



Please scan me for a quick reference on pitching this tent.



WARNING: Never unzip the zips on the protective sleeves whilst the Oxygen Air Frame Tubes are inflated. This will result in the tube bursting/ballooning out of the sleeve, causing damage to the tube *and* sleeve; this is NOT covered under the warranty!