

CANDOSA PIECE SET

11

CARE & MAINTENANCE GUIDELINES

1. Check and Tighten Fittings

Periodically inspect all bolts, screws, and fittings. Re-tighten as needed to ensure continued stability and safety.



2. Avoid Dragging

Do not drag or pull the furniture when moving it. Always lift and reposition carefully to prevent structural damage or stress on joints.

3. Cleaning Instructions

Clean the frame using a soft cloth dampened with mild water. Dry thoroughly with a clean, soft cloth to prevent moisture damage.

Do not use bleach, acidic solutions, solvents, or abrasive cleaners.



4. Cushion Care

Cushions are not waterproof. Store them in a clean, dry area when not in use to prevent moisture damage and mildew.

5. Seasonal Storage

During prolonged periods of wet, cold, or winter weather, store the furniture in a dry, sheltered area. Ensure all components are clean and completely dry before storage.

6. Treating Scratches

If the metal frame becomes scratched and bare metal is exposed, apply a rust-resistant paint promptly to prevent corrosion.

7. Use of Protective Covers

When not in use, we recommend covering the furniture with a suitable furniture cover to protect it from dirt, debris, and weather exposure.

