



# Assembly Instructions

## Knutsford Pavilion 2.4m

Code: 15221

V7 12 23




(W x D x H) 2.80m x 2.80m x 2.30m



**ONLINE ASSEMBLY VIDEO AVAILABLE**

Please scan the QR code or visit [zestoutdoorlivingsupport.co.uk](http://zestoutdoorlivingsupport.co.uk)



**PLEASE KEEP THESE INSTRUCTIONS**

## Every Zest product is unique because each piece of timber has its own distinctive, natural features



Zest is a leading timber specialist, designing and manufacturing award winning wooden garden products, crafted from natural slow-grown European redwood. Unlike man-made materials, timber is an entirely natural material, and each piece has its own distinctive qualities. So, owning a Zest timber product is like enjoying a unique slice of nature.

The benefits of slow grown timber:

“Trees grow slowly in the cold climate of Eastern Europe producing stronger and close grained timber ideal for making quality outdoor products.”



## Natural and Unique



There may be variations in the timber's colour or shading, but these will fade away over time when exposed to sunlight.



The changing seasons in each year of growth create characteristics unique to each tree - and to every piece of timber. Branches create an embedded mark in the tree trunk, resulting in a knot. Knots are a unique and natural feature which tells the story of the tree.



Owing to timber's natural moisture content, variations in temperature and humidity can cause expansion and contraction and may result in cracks and splits in any product made from natural timber. Any cracks and splits in the timber grain will alter with the changing seasons. They do not compromise the strength and durability of the product - they just add to its unique character.



Most Zest products are pressure treated which protects the timber from rot for many years. Pressure treatment can result in a small amount of 'green spotting' on the surface of new timber caused by natural salts leaving the wood. This will fade away over time.

These visible changes are not a fault or a cause for concern and do not affect the structural integrity of the product. They are a result of how the timber matures and responds to its natural environment.

### Ethically Sourced

Zest's slow grown European redwood is sourced from responsibly managed PEFC certified forests. This means forests are used in a way that maintains biodiversity, regeneration, and nature conservation. PEFC tracks certified timber from the forest to the final product giving complete confidence to the customer. [www.pefc.co.uk](http://www.pefc.co.uk)



### Replanting

Zest with its main supply partners is dedicated to replanting woodland and is collaborating on the nurture of wildlife habitats.

### Advisory Notices

- Roofs are weather resistant and not guaranteed to be watertight unless otherwise stated.
- Items with enclosed storage or cupboard space are weather resistant and are not watertight unless otherwise stated.
- Be aware of trap hazards if a Zest product has moving parts.
- All products should be positioned on solid, level ground
- Anchor down products where applicable using appropriate fixings.
- Roofs are not weight bearing
- Sanitise all catering surfaces prior to use.



# Knutsford Pavilion 2.4m Assembly Instructions

Requires 2-3 Person assembly


\*All Screw holes to be pre-drilled\*

Tools required: Corded / Cordless Drill, \*Pozi-drive bit (\*Crosshead) / 3mm & 5mm drill bits / Screwdriver, (Torx-Bits Included), Tape Measure, Mallet.

Please take a few moments to check all pack contents listed


Knutsford Pavilion 2.4m Pack List			
Code	Item	Description	Quantity
19810	A1	Angled Ring Beam	2
41328	A2	Straight Ring Beam	2
19811	B	Post	4
19812	C	Handrail	3
19830	D	Handrail Cover	3
19813	E	Bracing	8
19815	F	Rafter	4
19814	G	Finial Block	1
19816	H	Centre Rafter	4
19829	I	Roof Board Pack	4
19832	J	Long Cover Strip	4
19831	K	Short Cover Strip	4

18837 - Knutsford Pavilion 2.4m Fixings List		
Item	Description	Quantity
1	45mm Screws	252
2	60mm Screws	8
3	100mm Screws	16
4	120mm Screws	16
5	140mm Screws	16




This product is made from pressure-treated timber. It should not be painted or coated with any other treatment until at least 6 months after purchase

1



Set out Ring Beams A1 & A2 as shown above and fix in position using 8 x 60mm screws, (2 x 60mm Screws per corner.).


2



Position 2 x Posts (B) beneath Ring Beam (A1) and attach using 2 x 120mm Screws, (1 x 120mm screw per post.).







3



Place remaining Posts (B) beneath Ring Beam and fix using 2 x 120mm Screws, (1 x 120mm screw per post.).

4






Position 1 x Hand Rail (C) between Posts (B) at desired height and fix using 4 x 120mm Screws, (2 x 120mm per post.), Repeat for remaining 2 x Hand Rails (C)

5



Place 1 x Handrail Cover (D) onto Handrail (C) and fix using 4 x 45mm Screws.  
Repeat for remaining 2 x Handrail Covers (D) and Handrails (C)



6



Fix 1 x Bracing (E) to Post (B) & Ring beam using 2 x 140mm Screws as shown above.  
Attach remaining Bracings (E) to Posts (B) & Ring beam using 16 x 140mm Screws,  
2 x Screws per Bracing, 2 x Bracings per Post.






7





Attach angled end of 1 x Rafter (F) to Finial Block (G) allowing a 20–25mm gap between Rafter (F) and Finial Block Capping using 1 x 100mm Screw. Similarly attach 1 x Rafter (F) to opposite side of Finial Block (G)

8



Place rafter assembly diagonally onto ring beam and fix using 2 x 100mm Screws, (1 x 100mm Screw per rafter.).

9



Attach remaining 2 x Rafters (F) to Finial Block (G) using 2 x 100mm Screws, (1 x 100mm Screw per Rafter (F)), and to Ring beam using 2 x 100mm Screws (1 x 100mm screw per Rafter (G)).



10



Attach 1 x Centre Rafter (H) to Final Block (G) using 1 x 100mm Screw and to Ring beam using 1 x 100mm Screw.

Fix remaining 3 x Centre Rafters (H) in corresponding positions in roof sections as shown above, using 6 x 100mm Screws, (2 x 100mm Screws per rafter.).





Open 1 x Roof Board pack and set out as shown above (Top). Attach longest pair of square ended roof boards to Centre Rafter (H) and to Rafters (F) (allowing a 10–15mm overlap beyond rafter ends) using 8 x 45mm Screws. (4 x 45mm Screws per board, 2 x 45mm Screws per end).

Interlock shorter pair of square ended Roof Boards to fixed Roof Boards and continue to interlock subsequent Roof Boards. Fix all Roof Boards (I) to Rafters (F) and Centre Rafter (H) using 45mm Screws (3 x 45mm Screws per full board, 2 x 45mm screws for half boards.).


**Repeat this stage for remaining roof sections.**





Place 1 x Long Cover Strip (J) over joint in roof boards and under finial block capping (angled cut beneath capping and facing upwards). Fix in position using 8 x 45mm screws (2 x 45mm screws per end, 2 x 45mm either side of centre).

Repeat on remaining roof board joints using 3 x Long Cover Strips (J) (1 x Long Cover Strip per joint).



Position 1 x Short Cover Strip (K) centrally (angled cut beneath Finial Block capping and facing upwards) and fix using 6 x 45mm Screws, (2 x Screws per end and 2 x Screws to centre.) Repeat on remaining roof sections using 3 x Short Cover Strips (K)

**Knutsford Pavilion 2.4m is now complete.**